
# RTMe Rope Tension Meter

User Manual translation of original instructions



#### © Gigasense 2023

2023-08-10 | 237 - G

This user manual is protected by copyright law. It is prohibited to copy the contents of the publication without the consent of Gigasense. This ban applies to all forms of copying and digitisation.



# **Contents**

Introduction 4
Intended use 4
Scrapping and recycling 4
CE marking4
Manufacturer 4
Safety 5
General safety information5
Warning levels 5
Remaining risks 5
Design and function 6
Overview 6
Measurements 6
Different types of ropes 7
Battery 7
Operation and use 8
Before use 8
Resetting the instrument to zero 8
Measurement instructions9
Multipoint measurement
After use 10
Menu operation11
The function of the buttons 11
Menu tree
Normal view 13
Menu
Charging
Maintenance 18
Recalibration
Troubleshooting
Technical data20
Spare parts

## Introduction

#### Intended use

The RTMe rope tension meter is an instrument specifically designed to measure the forces in different kinds of ropes. Measurement is carried out quickly, without any extra preparation (unloading, etc.), and accurately on the tensioned rope. Avoid measuring near the rope attachments. Measurements can be carried out on ropes of different diameters, materials and designs.

The RTMe can include up to 20 different calibrations, i.e. measurements can be carried out on 20 different ropes (Rope Nos) without using conversion tables. The display shows the correct force for these ropes. The correct "Rope No." (calibration) can be selected by using the rope list in the instrument. To increase the accuracy of the readings, each rope is calibrated at four points. These are: 0%, 30%, 60% and 100% of the "Cal Cap" (maximum capacity).

Gigasense AB does not accept responsibility for any use of the product other than that for which it is intended.

## **Scrapping and recycling**

Comply with local recycling regulations when disposing of this product. The product must be disposed of separately, and not with normal household rubbish. Replaced and discarded parts can be sent to Gigasense AB for destruction.



## **CE** marking

Gigasense AB hereby declares that this product complies with the EU's essential health, environmental and safety requirements.



## **Manufacturer**

Gigasense AB Stationsvägen 16 184 50 Åkersberga SWEDEN Telephone: +46 8 540 839 00

info@gigasense.se www.gigasense.se

# Safety

Read the safety instructions before use. If you have questions about the safety or operation of the product, contact Gigasense or your authorised dealer.



## **General safety information**

To ensure safe operation, this user manual and the applicable local industrial safety rules and regulations must be complied with. It is also important to comply with the applicable national laws and safety regulations and directives relevant to the use of this product. The warranty is void if sealed screws are adjusted or if other changes not described in this manual are made.

## **Warning levels**

The warning levels in this document have the following meaning and formatting:



#### Caution

Indicates a risk that may occur. If the risk is not avoided, this may result in personal injury or damage to the product.

#### Important!

Used to reinforce important information that can facilitate understanding or the performance of a particular task.

## **Remaining risks**



#### Caution


The system must be taken out of service in the event of damage.

Personnel working with, installing and using the system are responsible for ensuring that they understand the instructions relating to its functions and the installation described in this manual. If there are any questions or uncertainties, Gigasense AB should be contacted before the system is put into operation.

Correct functioning must be verified before the system is put into normal operation.

# **Design and function**

# **Overview**



#### Fig. 1

1. Clamping jaw	2. Tightening device	3. Tightening screw	4. Centre support (flat)
5. Outer rope support	6. Display	7. Pushbuttons	8. Pull rod
9 Leaf spring unit	10 Load cell		

## Measurements

The RTMe can be used to carry out measurements in two different ways:

1. Tensioned rope.

The rope to be measured is loaded to the force X. The RTMe is installed and the rope force is read on the display.

2. Slack rope.

The RTMe is installed on the rope when it is slack. The rope is loaded to force X and then the rope force is read on the display.

Experience has shown that a better measurement result is obtained when using method 1 above. All RTMe ("rope numbers") are normally calibrated for measurement using method 1.

## **Different types of ropes**

The best accuracy is obtained when measurement is carried out on a rope that is identical to the calibration rope. Different types of ropes can be calibrated for the instrument. For example, steel ropes, copper ropes, parallel filament ropes, textile ropes etc.

Gigasense recommends using the instrument against a calibrated rope.

## **Battery**

The RTMe rope tension meter is powered by a rechargeable 1-cell 3.7 V lithium-ion battery with a battery life of 60 hours. The battery is charged via a USB-C charger. The charger must have a capacity of at least 0.5 A.



#### Caution

The RTMe only works with an 850 mAh rechargeable battery type 14500. The battery must have a built-in protection circuit. The RTMe is supplied with a Nitecore NL1485 battery.

# **Operation and use**

#### **Before use**

- Check that the instrument's battery is charged.
- Check that the threads of the tightening screw are clean and well lubricated.

## Resetting the instrument to zero

The instrument can be reset to zero in two different ways:

1. Hold the RTMe in a vertical position suspended from the handle.

Then press and hold the **Select/Zero** button for about 2 seconds.




Fig. 2

2. Let the RTMe rest on the upper supports – not tightened.

Then press and hold the **Select/Zero** button for about 2 seconds.

#### Important!

When zeroing, make sure that the tightening screw is loose and does not pinch the rope.




Fig. 3

#### **Measurement instructions**




Fig. 4

- 1. Reset the instrument to zero in accordance with *Resetting* the instrument to zero, page 8.
- 2. Select the correct "Rope No.", depending on the rope to be measured. See also *Multipoint measurement*, page 13.
- 3. Using the tightening screw (B), unscrew the clamping jaw (A) sufficiently to make room for the rope.
- 4. Attach the RTMe so that the outer rope supports (C) are in contact with the rope.



#### **Caution**

Avoid measuring near the rope attachments.

- 5. Turn the tightening screw (B) until the rope is in contact with the centre support (D).
- 6. Turn the tightening screw another 1/4 to 1/2 a turn to obtain the correct clamping force.



#### **Caution**

Note that the rope must not be deformed. For copper rope, no additional tightening is required.

7. The measurement result on the display shows the tension force in the rope. The reading on the screen must be obtained within a 2–4 second time period. After this period of time, depending on the type of rope, the value starts to slowly decrease.

## **Multipoint measurement**




Fig. 5

#### Important!

You can save up to 6 measurement points in the instrument.


- 1. Reset all measurement points to zero by placing the cursor on "Clear all" (*Multipoint measurement*, page 13) and pressing the **Enter** button.
- 2. Select "=> 1" and place the instrument on the first measurement point. Carry out the measurement as described in steps 3-7 *Measurement instructions*, page 9. Save the value by pressing the **Enter** button. Carry out the same procedure for measurement points 2–6.

## **After use**

- Any dirt in the threads of the tightening screw must be removed. Lubricate if necessary.
- Clean and charge the instrument if necessary.
- Store and transport the instrument in the transport box provided.

# Menu operation

### The function of the buttons



#### Fig. 6

- 1. Starts/turns off the instrument
- 2. Starts and exits menu operation
- 3. Select: Selects the selected indication Zero: zeroes the display
- 4. Moves up a value/moves cursor upwards. Scrolls between menus.
- 5. >1s saves the parameter
- 6. Moves down a value/moves cursor downwards. Scrolls between menus.

When scrolling in the menus, a cursor, "->", is used to indicate the selected function or menu. If the selected function is password protected, the cursor changes to "--".

#### Menu tree




Fig. 7

#### **Normal view**

At start-up, the normal view is displayed. The following are presented:

- Capacity (in the selected unit).
- Current measured value (in the selected unit).
- Rope selected.

Press **Up/Down** to scroll between *Multipoint measurement, Battery indication,* and *Detailed view.* 

## **Multipoint measurement**

 Multi-point measurement is used to measure and obtain an overview of several measurement points at the same time. The pointer "=>" is moved using Select. When Enter is pressed for 2 seconds, the current measured value is saved for the selected position. When the pointer is set to "Clear all" and Enter is pressed, all saved points are reset to zero. Capacity 16.54 t

15.12

Rope 011 7.3mm 1x7

Multipoint measuring

10.00 kN

=>1=3.00 2=5.00
3=7.00 4=9.00
5=11.00 6=12.00
Clear all
Sel=step, Enter=save

### **Battery indication**

The following is displayed:

- Est. op.time: Expected remaining operating time in hours.
- Battery: Current battery voltage. The battery should not be charged to more than 4.20 V. Below 3.50 V, the instrument will automatically switch off.
- Capacity: Remaining battery capacity.
- **Not charging**: Information as to whether the battery is charging or not.

Battery info.

Est.op.time 22h
Battery= 3.80V
Capacity= 39%
Not charging

Use +, - or Menu

#### **Detailed view**

The following is displayed:

- **Instr. value**: Value after instrument calibration. The normal range is 0–10,000 scale units.
- **Rope value**: Value after calibration on the rope, 0–10,000 scale units.
- **Zero corr. (%)**: Shows what percentage of the capacity has been reset.
- **Load value**: Value after conversion according to the rope capacity in kN.
- Grade value: Conversion from kN to the selected unit.
- **Rope**: rope selected.

## RTM load

Instr. value 9997
Rope value 9966
Zero corr.(%) 0.00
Load kN value 14.28
Load ton value 1.453
Rope 018 17.7mm 1x19

### **Display messages**

• The measured value is displayed in large text. In the event of an overload, the measured value alternates with the text "Rope overload! > 50%" on the screen. 50% means that the overload parameter is set to 50%.

Rope overload! > 50%

• If the battery voltage is too low, "Low battery" is displayed on the line below the measured value.

Low battery 3.50V

• If there is a sensor alarm, no measured value is displayed, instead "Sensor Alarm!" is displayed.

# Sensor alarm!

 Zero taring, press and hold Zero for 1 second. The display shows 0. The zeroed value in % is displayed for 2 seconds.

Zeroing ok 0.01%

• If zeroing fails, the signal value is outside a permitted range, "Zeroing failed" is displayed.

Zeroing failed 1.09%

• Zeroing is reset when the instrument is restarted.

### Start-up with a low battery voltage

 When the instrument is started with a battery voltage below 3.50 V, a warning text is displayed for about 5 seconds and then the instrument switches off automatically.

• If the battery voltage is too low, the instrument will not start. Charge the battery and then start the instrument again.

Critically low battery voltage

Forcing turn off!

#### Menu

Press **Menu** to display a list of functions. Move the cursor using **Up/Down** and then press **Select** to start the selected function.

### **Select rope**

A submenu of calibrated ropes is displayed. Move the cursor using **Up/Down** between pre-calibrated ropes.

 Press Enter for about 1 second to select the highlighted rope.

```
Main menu
-> Select rope
   User parameters
   Settings

Use +, - or Select
```

#### **Rope selection**

One of up to 20 pre-programmed ropes can be selected. The rope number, diameter, structure and maximum permitted load are displayed.

The activated rope is marked with an "\*" on the far right. Move the cursor ">" using **Up** or **Down**. If the last line is selected, the next 5 lines are displayed if **Down** is pressed.

```
Rope Dia Con kN
>010 15.3 1x7 41
011 6.0 2x7 68*
022 7.3 3x7 79.1
033 9.2 4x7 90
044 9.8 5x7 106
Rope list no. 1...5
Use +, - or Enter
```

### **User parameters**

Change parameters that affect the display and function. Move the cursor using **Up/Down** between functions. Press **Select** when the desired function is highlighted.

```
User Parameters
-> Unit
Signal filtering
Overload limit
Auto turn off
Handle neg. load
Display resolution
Use +, - or Select
```

#### Unit

Select an appropriate unit from the following: 'kN', 't', 'lbs', 'daN' and 'USt'. An \* indicates the unit that has already been selected. Select view using **Up** or **Down**. Press **Enter** for about 1 second to save the selected unit.

```
Select Unit
-> kN*
t
lbs
daN
USt

Use +, - or Enter
```

#### Signal filtering

Select the filtering value for the selected rope: 1–10 s. The instrument calculates the average value during the set time, which means that increasing the filter time increases the inertia in the display. The setting applies to the selected rope.

```
Seconds 01

Enter (1-2s)=save
Use + or -
Use Menu to exit
```

#### **Overload limit**

Select the limit at which the instrument should indicate an overload. The limit is set as a percentage of the capacity. The setting only applies to the selected rope.

```
Overload limit

Rope=11
Limit in % 100

Enter (1-2s)=save
Use + or - or Select
Use Menu to exit
```

#### **Auto turn-off**

Select the number of minutes until the device automatically switches off when not in use: 0–60 min. The minute counter is reset to zero each time the button is pressed.

```
Auto turn off

Minute 00

Enter (1-2s)=save
Use +, - or Select
Use Menu to exit
```

#### Handle neg. load

Select "Yes" to not indicate a negative load. Any load below zero is indicated as 0.

```
Handle neg. load

Suppress neg. load

->No Yes

Enter (1-2s)=save
Use Select to change
Use Menu to exit
```

#### **Display resolution**

To limit the resolution, select one of the following values: 1, 2, 5. The setting is unique to each rope.

```
Display resolution

Rope 011
Last digit 1

Enter (1-2s)=save
Use + or -
Use Menu to exit
```

## **Settings**

View and change general settings on the instrument. Move the cursor using **Up/Down** between functions. Press **Select** when the desired function is highlighted.

Instrument info: Information about the instrument.

• **Display contrast**: Change the contrast for optimum readability. Selectable between 0 and 63.

• Sensor info: Information about the sensor.

• Log in: For Gigasense use only.

• Calibration setup: For Gigasense use only.

• Calibration menu: For Gigasense use only.

## **Charging**

- Charging starts when a USB-C cable is plugged into the socket.
- When charging is started, the instrument enters charging mode regardless of its previous state.
- When charging ends, the instrument always switches off.
- Note that the indicated voltage increases during charging and decreases when charging ends.
- When the battery voltage is above 4.20 V, the text "Remove charger!" is displayed.
- If the battery voltage goes above 4.3 V, charging is switched off. The display shows the charging current being used.

Settings

-> Instrument info
Display contrast
Sensor info
Log in
Calibration setup
Calibration menu

Use +, - or Select

Instrument info

Serial no. 10 Hardware rev. 1.00 Software rev. 2.00

Press menu!

Display Contrast

Contrast 30

Enter (1-2s)=save Use + or -Use Menu to exit

Sensor info Type A200

No login! Press Menu!

## RTM charge

Est.op.time 22h
Battery 3.80V
Capacity 39%
Charging 450mA
Measurement disabled,
remove charger
to start a measurement

# **Maintenance**

The RTMe is designed to be maintenance-free. When cleaning the equipment, this should be done by gently wiping it with a dry or damp cloth.

#### Recalibration

To maintain the measurement accuracy of the RTMe, it is recommended that the instrument be sent to Gigasense for recalibration on a regular basis. How often it needs to be recalibrated depends on how often it is used. In general, it is recommended that the instrument be sent in for recalibration every two years. If the instrument is in frequent use, such as several times a day, it is recommended that it be sent in for recalibration every year.

# **Troubleshooting**

If the RTMe does not work, please check the following before contacting Gigasense or your local authorised dealer:

Error	Cause	Solution
"Zeroing failed" is displayed during zeroing.	The sensor's zero value has changed by more than 1.5%.	Recalibration at Gigasense required.
The RTMe does not start.	1. The battery is discharged.	1. Charge the battery.
	<ul><li>2. The battery is defective.</li><li>3. The electronics have "hung".</li></ul>	<ol><li>Replace the battery with a new one of the same type and charge.</li></ol>
	4. The battery is fitted in the wrong orientation.	3. Remove and refit the battery.
		<ol><li>Turn the battery so that + terminal is facing the bat- tery hatch.</li></ol>
		If none of the above works, send the RTMe to Gigasense for repair and troubleshooting.
Charging does not work.	The USB-C connector is not inserted properly.	1. Push the USB-C connector in until it stops.
	<ol><li>Faulty charging cord or power adapter.</li></ol>	<ol><li>Replace the charging cord or power adapter.</li></ol>
	3. Charging function error in RTMe.	3. The RTMe needs to be repaired at Gigasense.
		If none of the above works, send the RTMe to Gigasense for repair and troubleshooting.
The RTMe does not respond to button presses.	The electronics have "hung".	Remove and reinsert the battery.
·		2. Electronics fault, send to Gigasense.
"Sensor alarm!"	The connector to the sensor has come loose.	Make sure the sensor connector is tightened.
		If none of the above works, send the RTMe to Gigasense for repair and troubleshooting.



# **Technical data**

	RTMe 5 t	RTMe 20 t	
RTMe Max.cap. kN/t/lbs	50/5/11,000	200/20/44,000	
Rope diameter	Approx. 0.23"–1.5"/6 mm–38 mm		
Main dimensions of RTMe	(LBH) 26.97" x 5.51" x 14.96"/685 x 135 x 380 mm		
Net weight of RTMe	6 kg	6 kg	
Main dimensions of transport box	(LBH) 29.92" x 6.69" x 15.75"/760 x 170 x 400 mm		
Weight (RTMe + transport box)	11.2 kg	11.2 kg	
Inaccuracy (depending on rope type and characteristics)	Up to a maximum of ±2% for steel ropes and ±6% for copper ropes.		
Maximum number of calibrated ropes	20		
Permitted ambient temperature	-4°F–140°F/-20°C–60°C		
Display	LCD screen		
Digit size	0.47"/~12 mm for load display. 0.157"/4 mm for other display text		
Battery service life (hours)	60 hours rechargeable		
Battery specifications	Nitecote NL1485 Lithium ion 1-cell 3.7 V 850 mAh type 14500		
Protection class (IEC 529, NEMA)	IP65		
Material	Anodised aluminium		

Max Cap = Max. capacity of RTMe

Cal Cap = Max calibrated capacity for each rope

