


# TS1-A10 - Sensor without integrated amplifier with Strain gauge amplifier SCV-1

outputs: analog 0 - 1 V


Info: TS1-A10( 1) – SCV-1 -011



# MZ-A10 - Sensor without integrated amplifier with Strain gauge amplifier SCV-1

outputs: analog 0 - 1 V


Info: MZ-A10( 1) – SCV-1 Standard -010



# TS1-A10 - Sensor without integrated amplifier with Strain gauge amplifier SCV-1-A2

outputs: analog 0 - 10 V


Info: TS1-A10( 1) – SCV-1-A2 -011



# MZ-A10 Sensor without integrated amplifier with Strain gauge amplifier SCV-1-A2

outputs: analog 0 - 10 V


Info: MZ-A10( 1) – SCV-1-A2 -002



# TS1-A10 Sensor without integrated amplifier with Strain gauge amplifier SCV-1-A3

outputs: Current output 4 - 20 mA

Info: TS1-A10( 1) – SCV-1-A3 -011



# MZ-A10 Sensor without integrated amplifier with Strain gauge amplifier SCV-1-A3

outputs: Current output 4 - 20 mA

Info: MZ-A10( 1) – SCV-1-A3 -002

