STARTING THE LOGGER

- On the Device Connected page, slide the switch to start the logger.
- Enter the Log Details and settings and tap Start.



DOWNLOADING THE DATA

 Tap below the Log information to Download or Update the Log Data



VIEW / SHARE THE DATA

- Tap the icons at the the foot of the page to view live data.
- Tap below the Log information to View Log Chart.
- Via the Menu, go to Project to view a list of Logs and Projects.
- Tap on a Log to view the Saved Data.
- From the chart view, you can export or share chart images or data tables in CSV format.

WARRANTY

 Obtain Warranty online: tramexmeters.com/register

ONLINE INFORMATION PAGES

 Please use the following link or QR code to access further information on Feedback Data Loggers online:



LI-DL-RHTXOSGUS





FEEDBACKDATA LOGGER

TEMPERATURE AND RELATIVE HUMIDITY DL-RHTX



QUICK START GUIDE



Distributed by: ABQ Industrial LP USA **Tel:** +1 (281) 516-9292 / (888) 275-5772 **eFax:** +1 (866) 234-0451 **Web:** https://www.abgindustrial.net **E-mail:** info@abgindustrial.net

GET STARTED

- Download the Tramex Feedback app from the App Store or Google Play.
- Register (in-App) to create an account.
- Remove the Battery tab and dust cover.
 [Readings can not be taken with dust cover on.]
- Connect the optional contact temperature probe.
- Push in and twist interface cable (1).





- Connect Hygro-i2® probe (2).
- Switch the O/I button to I. This starts the logger transmitting to the app.

CONNECTING

 When transmitting, your Feedback device should appear on the device list.



 Tap to select your device from the list to go to Device Selected page.





- Onsite photos showing RH and temperature values can be taken and saved.
- Tap connect to operate the device.



DATA LOGGER IDENTITY

 Label each Feedback Data Logger with a different color/number combination to allow easy identification



• Tap the yellow pencil icon to assign it a color and number.

