
Distributed by: ABQ Industrial LP USA

Tel: +1 (281) 516-9292 / (888) 275-5772 eFax: +1 (866) 234-0451


Web: https://www.abgindustrial.net E-mail: info@abgindustrial.net



Note 'A': Mounting instruction 1. Use Socket Head Cap Screw for mounting QC

- 2. Bolt Size: %-16 SHCS
 3. Secure into threaded plate: 1' thick for aluminum plate, 0.5' minimum for steel plate.
- 4. For thru hole mounting in a wooden bench, bench thickness should be ¾ thick minimum. Use a backing washer as shown. 5. Maximum capacity is 500 lb. ft.

- 6. QC should never be mounted directly an a wooden bench top. Use of a sub plate of at least %" thick with a 6" x 9" foot print ls recomended.
- 7. Disclaimer: the above instructions are intended as quidlines only. AWS bears no liability for flature of product when mounted to any bench or apparatus not supplied by AVS, Inc.



Distributed by: ABQ Industrial LP USA

Tel: +1 (281) 516-9292 / (888) 275-5772 eFax: +1 (866) 234-0451 Web: https://www.abgindustrial.net E-mail: info@abgindustrial.net