

## TROUBLESHOOTING

- All LED's flashing when unit is powered up.
  - Battery is low and will soon need to be replaced with an Alkaline battery.
- Single LED flashing and meter frozen.
  - Skipper Plus is in HOLD mode.
  - Press HOLD button to release.

## USER GUIDE ONLINE

Please use the following link or QR code to access the complete User Guide online:  
<http://lead.me/bax06y>



# SKIPPER Plus



## QUICK START GUIDE

## OPERATION

- Press the ON/OFF button.
- Press Range button to select the required mode.



- Press Skipper Plus fully against the surface of the material.



- Readings are instant and displayed on the analog screen.
- Last range used is memorized when power is shut down and automatically selected next time unit is powered up.
- Turn Audio signal on or off by pressing HOLD/AUDIO twice in quick succession.
- To freeze the readings press the HOLD/AUDIO button once, LED for selected range will flash slowly.

- If Skipper Plus is shut down in HOLD mode it will retain the stored reading when powered up next and remain in HOLD mode with the LED for the selected range flashing.
- Automatic power timeout (10 mins) conserves battery life.

## SCALE USE

- Upper scale (5-30) indicates moisture content (MC%) of wood when used on wood products.



- Lower scale (0-100) is a comparative scale and may be used for recording and comparing moisture condition in GRP and other materials.

## CALIBRATION & WARRANTY

- Obtain Warranty online: [tramexmeters.com/register](http://tramexmeters.com/register)
- Annual calibrations are recommended as best practice. Calibration Check Boxes can be purchased for regular checks:



Product code: CALBOXSMP