



CALIBRATION GUIDE GALVANIC DO

OBJECTIVE

Procedure for calibrating the Galvanic DO sensor.

PREPARATORY STEPS

1. Check

Check that the membrane cap does not need to be replaced. Look to see if there is filling solution inside the cap through the membrane. If when observed, the cap appears dry inside or there is a large build up on the electrode, then the cap should be replaced with fresh electrolyte solution and the electrode polished. Caps should be replaced once a month, electrode should be polished to remove white build up at each cap change.

2. Required Items

- Zero oxygen calibration solution
- A moist cloth/towel
- Water bath set to 25°C, where possible.

3. Preparation

The zero oxygen solution should be placed in the water bath, so that the temperature is brought up to 25°C. If no water bath is available, the solutions should be placed on the bench so that they can reach room temperature overnight, prior to starting the calibration procedure.

Remove the pH storage cap from the probe's pH sensor prior to probe insertion.

4. Conditioning

If using a water bath, or calibrating on the bench, the Aquaprobe should be placed into the calibration solution, for approximately 20 minutes so that the temperature of the probe and calibration solution can reach equilibrium and so that the DO reading displayed on the Aquameter screen reads 0%.

5. Equipment

- Aquaprobe.
- Calibration instrument; Aquameter / Bluelink / Aquacal PC software
- Chosen calibration solution.
- Water bath.





OPERATING MODE

CALIBRATION

Calibration guidance will assume you are using an Aquameter, procedure will be similar when using Bluelink or AquaCal.

If you are performing a full 2 point calibration; 0% and 100%, then the 0% calibration **MUST** always be performed first.

Procedure:

1. With the Aquaprobe having soaked in the calibration solution for 20 minutes ensure the DO is reading close to 0% and that the temperature is stable.
2. Select the desired calibration solution. Press the MENU key then select Calibration>Full Cal>DO/EC to enter the DO/EC calibration screen.
3. Move the cursor downwards to the correct calibration solution option, for example DOZero.
4. Once your desired calibration option is selected, press the OK button on the Aquameter to begin the calibration process.
5. A calibration report value will be displayed after the calibration is complete.
6. Wash and dry the probe, ensuring there are no water droplets on the DO membrane cap before performing the 100% calibration.
7. Moisten a clean cloth or piece of tissue paper with fresh water and wrap it around the open end of the probe ensuring all the holes are covered (ensure the probe sleeve is fitted). Place the probe at a slight angle so the DO tip is pointing down (preferably tip downwards in a clamp). Do not hold the probe, the heat from your hands will warm the probe up and interfere with calibration.
8. Select the desired calibration solution. Press the MENU key then select Calibration>Full Cal>DO/EC to enter the DO/EC calibration screen.
9. Move the cursor downwards to the correct calibration solution option, for example DO100%.
10. Once your desired calibration option is selected, press the OK button on the Aquameter to begin the calibration process.
11. A calibration report value will be displayed after the calibration is complete.

CONTROL

Check the calibration report value is within the acceptable range.

The acceptable range for the 0% calibration is 0-10mV

The acceptable range for the 100% calibration is >26mV

Once calibration is complete press the escape button until you can see the live readings. Check that the DO reading in air is 100%.

Dated	Revision	Document evolutions	Author
25/11/24	0	Creation	CP
26/11/24	1	Reviw and fine adjustment	GP

