

## MODEL DD-4 DIGITAL DUROMETER OPERATING INSTRUCTIONS SUPPLEMENT

### To Store Readings:

1. Press and release **2ND** button.
2. Press and release **HOLD** button.

The number that is displayed when hold is released will be stored in the durometer (⊖ appears on screen for approx. 2 seconds).

### To View and Scroll Through Readings:

1. Press and release **2ND** button.
2. Press and hold **HOLD** button for 3 seconds then release when the screen changes and a ⊖ and number appear.

The sequence number of the reading will be displayed first then the value of it, beginning with the most recent reading.

3. Press **MOVE (2ND)** button to scroll through the readings.

The durometer will store up to 200 readings, then will delete readings beginning with the oldest one first.

### To Exit Stored Reading Viewer:

1. Press and release **APPLY (HOLD)** button and the ⊖ will disappear from screen.

### To Clear All Stored Readings: (Must be in "View" mode)

1. Follow directions above to enter view mode.
2. Press **ON/CLR** button until nonE appears on the screen.
3. Press and release **APPLY (HOLD)** button to exit.

Use our **USB Data Output cable (Model G01-0020)** to download readings to a computer.