CALIBRATION & WARRANTY

- Obtain Warranty online: tramexmeters.com/register
- Annual calibrations are recommended as best practice to ensure continued accuracy and reliability. Calibration Check Plates can be purchased for more regular checks:



Product code: CALCRH

 Check the calibration of the CMEX2 Pin-Probe mode with a set of 3-value Calibration Check Plugs:



Product code: PTMCAL SET

 Check the calibration of Tramex Hygro-i2 RH probes (as per ASTM & International Standards) with Calibration Check Salts:



Product Code: SAL75

TROUBLESHOOTING

- Flashing "H" on home screen & readings frozen.
 - Meter is on Hold.
 - Release Hold by pressing (1) once.
- "NO PROBE" on screen when RH probe cable is connected
 - Check Hygro-i2 probe is attached and connected properly.
- When replacing the battery always ensure to use an Alkaline battery.

USER GUIDE ONLINE

Please use the following link or QR code to access the complete User Guide online: l.ead.me/barXc1



LI-CMEX2QSGEU







QUICK START GUIDE



Distributed by: ABQ Industrial LP USA

Tel: +1 (281) 516-9292 / (888) 275-5772 eFax: +1 (866) 234-0451

Web: https://www.abqindustrial.net **E-mail:** info@abqindustrial.net

OPERATION

- Press 🖰 to switch ON/OFF.
- Press to select the required mode
 - CONCRETE **⑤**..PIN PROBE **⑥**..CM EQ CONCRETE 0-4%..
 - **(C)**..GYPSUM 0-12..
 - 🕏 ..REF 0-99...
- Press the CMEX2 fully against concrete slab or screed surface. (Surface should be smooth and free of coatings/contaminants)



• Instant readings displayed on digital screen.



 Last scale used is memorized on power shut down and automatically restored on next power up.

- Audio signal: Press (1) twice in quick succession.
- Hold/freeze: Press ① once. "H" will flash on the screen. Press ② again to release hold.
 (If powered down while on Hold, will retain information until powered up and hold pressed again to release)
- For Language, Backlight Timeout and C°/F° selection please refer to the online User Guide.
- Automatic power timeout (10 mins) conserves battery life.

NON DESTRUCTIVE MODE

- **CONCRETE scale:** use on Concrete slabs and Sand/Cement screeds.
 - MC% Moisture Content by mass/weight readings.
- CM EQ CONCRETE scale: use on Concrete slabs and Sand/Cement screeds.
 - Equivalent reading to Carbide Method (CM) test for Concrete.
- **GYPSUM scale:** use on Gypsum floors/screeds.
 - Reference readings replicating measurements using concrete scale on concrete & sand/cement floors/screeds.
- REF scale: use where direct contact to bare concrete is not possible due to very thin coating or covering on the concrete or for nonconcrete/screed materials such as ceramic tiles or stone.
 - Comparative/qualitative scale only to help identify areas with moisture.

PIN-PROBE WOOD/WME MODE

- Press to get to Pin-Probe screen.
- Plug the pin-probe (if purchased) into socket at top of the instrument.



• When pins are inserted into wood, measurements of 7% to approx. 50% are displayed.

RELATIVE HUMIDITY (RH) MODE

• Plug the RH Probe (if purchased) into the DIN socket at the top of the instrument.



 The CMEX2 automatically switches into Hygrometer mode, displaying readings of RH%, Temperature, Dew Point & Mixing Ratio.



For information on how to perform Equilibrium Relative Humidity (ERH) testing of concrete and other floor screeds see the online user guide.